



Event & Party Rental

8oz POPCORN MACHINE OPERATING TIPS

We recommend you buy the pre-measured packages of Popcorn with oil. Before you turn on make sure that the popcorn machine is secure on a dry, level surface that is away from any water. Read all instruction prior to using popcorn machine.

1. Connect to proper grounded 120-volt supply.
2. Turn on LIGHT switch. Light in cabinet will come on.
3. Turn on KETTLE/MOTOR switch and KETTLE/HEAT switch (located next to LIGHT switch) and wait about 2 to 4 minutes. **DO NOT** wait in between batches, only for initial startup.
4. Place 1/3 cup of oil in kettle. Immediately add 1 cup of raw popcorn plus 1 tsp or desired amount seasoning salt. Or use pre-measured packages of popcorn with oil.
5. When popping has finished, turn off heat and stirring motors; then dump remaining popped corn from kettle by rotating handle clockwise 1/3 turn and pulling downward. (Light will help keep the popped popcorn warm.)
6. Repeat steps 3-6 for additional batches of corn, remembering not to wait the 2 to 4 minutes for kettle to heat.
7. Always turn KETTLE/HEAT switch off first and KETTLE/MOTOR switch OFF after heat switch is off. Do not leave heat motor on when machine is not in use.
8. NEVER USE WATER ON ANY PART OF THE KETTLE!
9. Only use soft cloth to wipe out cabinet. DO NOT USE ANY FORM OF CLEANERS ON ANY PART OF POPCORN MACHINE.
10. DO NOT LEAVE MACHINE UNATTENDED WHILE IN USE.