



Event & Party Rental

BOUNCE HOUSE OPERATING INSTRUCTIONS

1. Bounce House Rental includes: **Bounce House, blower, tarp and 2 stakes.**
2. If power source is more than 15' from Bounce House, you will need a heavy duty extension cord at least 12-3 gauge and no longer than 100'. If this isn't possible you may need a generator.
3. Make sure the area for the bounce house is level and free from animal droppings, bigger rocks, anything sharp, then lay down the tarp that is provided.
4. Unroll Bounce House on top of the tarp; the center of backside of the Bounce House is starting point. Blower tube should be showing when Bounce House is rolled up.
5. Attach blower tube to the blower. Make sure tube is not twisted when attached to blower.
6. Close vents at rear and side of Bounce House by closing zippers and Velcro over the zippers.
7. Attach blower to power source and turn on switch.
8. Bounce House will inflate in 5 minutes or less. **Check blower tube for twists and bends again at this time.** When fully inflated, Bounce House can more easily be moved into exact position for staking.
9. Staking is required for outdoor use. Two stakes are provided and they are to be put in opposite corners of the bounce house. They are only for holding the bounce house in place while children are using it. They are NOT to keep the wind from blowing it away. In case of wind, children must be removed from bounce house immediately and it must be deflated. If it is very windy you may need to roll up the bounce house and put it in a secure place.
10. If at any time the bounce house is not fully inflating, check blower tubes, that very little air is escaping. Check that the zippers and Velcro on the sides of bounce house are closed completely. And check the blower air intake, to make sure nothing is blocking it from getting proper amount of air.
11. No water or sprinklers are allowed in or near the bounce house. Bounce houses that come back wet will result in a drying fee of at least \$200.
12. No pets are allowed in the bounce house.

CAUTIONS:

- 1. IF POWER IS INTERRUPTED FOR ANY REASON TO BLOWER, BOUNCE HOUSE WILL IMMEDIATELY DEFLATE!!**
- 2. MAKE SURE BOUNCE HOUSE IS THE ONLY ITEM USING POWER SOURCE.**
- 3. IF WINDS EXCEED 15 MPH IMMEDIATELY UNLOAD RIDERS AND DEFLATE.**